












## ZIP 33i ICON DESCRIPTIONS

| Icon  | Description                                |
|---|--|
|    | Network is unavailable                     |
|    | Hands-free speakerphone mode               |
|    | Handset mode                               |
|    | Headset mode                               |
| 123   | Numeric input mode                         |
| abc   | Multi-lingual lowercase letters input mode |
| ABC   | Multi-lingual uppercase letters input mode |
| 2aB   | Alphanumeric input mode                    |
|  | Voice Mail                                 |
| AA  | Auto Answer                                |
| DND   | Do Not Disturb                             |
|  | Call Forward                               |
|  | Call Mute                                  |
|  | Keypad Lock                                |
|  | Received Calls                             |
|  | Dialed Calls                               |
|  | Missed Calls                               |